




1. Gate Installation

1.1. Install Easy Installation Accessories





Install Cabinet Base and Inter-lane Plates - Quick Installation

1.2. Remove Cover Panels



1.3. Install Cabinets




Install Cabinet - Quick Installation

1.4. Connect Cables (Daisy-chain)


Connect the base cable and the power cable extending from the cabinet using aerial connector

Connect the base cable's Ethernet cable to the network port on expansion board


Connect the fire alarm signal wires to the dry or wet interface on expansion board of the nearest cabinet




1.5. Install Lane Glass Panels



① Remove the silicone plugs and screws at both ends of the rotating shaft




② Fix the glass panel to the rotating shaft




③ Insert the silicone plug


1.6. Install Wall-side Partition Glass Panels




① Unlock, rotate and lock



② Remove the silicone plugs and screws at both ends of the rotating shaft



③ Fix the glass panel to the shaft




④ Insert the silicone plugs

2. Set Up Company


2.1. *Gate Mgmt* Software

The corresponding version of the *Gate Mgmt* software can be downloaded and

installed via the software download portal: <https://www.exquisite-tech.com/GateWeb/index.html#/>.



2.2. Set Up Company



Server type: Cloud platform - Amazon

* Account: 18986160523




* Password: [Reset Password](#)

☒ Confirm [Privacy Policy](#) [Account Help](#)

[Login](#)

☐ Auto Login (Use with caution on public computers)

Quick Reference of Quick Installation




3. Gate Initialization


3.1. Install *Gate Setup* App




3.2. User Login (phone number/email + verification code)



3.3. Create a New Speed Gate Group









Quick Reference of Quick Installation




3.4. Initialize Each Lane




Quick Reference of Quick Installation




Quick Reference of Quick Installation



3.5. Config Network



Quick Reference of Quick Installation



4. Complete Installation

